

LES CONTROLLEURS

Dec	Hexdec	Nom Controlleur		Dec	Hexdec	Nom Controlleur	
0	00	VOICE	MSB	64	40	SUSTAIN	
1	01	MODULATION	MSB	65	41	PORTAMENTO PEDAL	
2	02	BREATH-CONTR	MSB	66	42	SOSTENUTO	
3	03		MSB	67	43	SOFT PEDAL	
4	04	FOOT CONTR	MSB	68	44	LEGATO FOOTSWITCH	
5	05	PORTAMENTO TIME	MSB	69	45	HOLD PEDAL 2	
6	06	DATA ENTRY	MSB	70	46	SOUND VARIATION	
7	07	VOLUME	MSB	71	47	CONTENU HARM TIMBRE	
8	08	BALANCE	MSB	72	48	RELEASE	
9	09		MSB	73	49	ATTACK	
10	0A	PAN POT	MSB	74	4A	BRILLANCE	
11	0B	EXPRESSION	MSB	75	4B	SOUND CONTROL 6	
12	0C		MSB	76	4C	SOUND CONTROL 7	
13	0D		MSB	77	4D	SOUND CONTROL 8	
14	0E		MSB	78	4E	SOUND CONTROL 9	
15	0F		MSB	79	4F	SOUND CONTROL 10	
16	10		MSB	80	50	SWITCH 1 (ON/OFF)	
17	11		MSB	81	51	SWITCH 2 (ON/OFF)	
18	12		MSB	82	52	SWITCH 3 (ON/OFF)	
19	13		MSB	83	53	SWITCH 4	
20	14		MSB	84	54	PORTAMENTO CONTENT	
21	15		MSB	85	55		
22	16		MSB	86	56		
23	17		MSB	87	57		
24	18		MSB	88	58		
25	19		MSB	89	59		
26	1A		MSB	90	5A		
27	1B		MSB	91	5B	EFF SEND 1 (REV)	
28	1C		MSB	92	5C	EFF SEND 2 (TREM)	
29	1D		MSB	93	5D	EFF SEND 3 (CHOR)	
30	1E		MSB	94	5E	EFF SEND 4 (DETUNE)	
31	1F		MSB	95	5F	EFF SEND 5 (PHASE)	
32	20	VOICE	LSB	96	60	DATA INCREMENT	
33	21	MODULATION	LSB	97	61	DATA DECREMENT	
34	22	BREATH-CONTR	LSB	98	62	NRPN	
35	23		LSB	99	63	NRPN	
36	24	FOOT CONTR	LSB	100	64	RPN	
37	25	PORTAMENTO	LSB	101	65	RPN	
38	26	DATA ENTRY	LSB	102	66		
39	27	VOLUME	LSB	103	67		
40	28		LSB	104	68		
41	29	BALANCE	LSB	105	69		
42	2A		LSB	106	6A		
43	2B	PAN POT	LSB	107	6B		
44	2C	EXPRESSION	LSB	108	6C		
45	2D		LSB	109	6D		
46	2E		LSB	110	6E		
47	2F		LSB	111	6F		
48	30		LSB	112	70		
49	31		LSB	113	71		
50	32		LSB	114	72		
51	33		LSB	115	73		
52	34		LSB	116	74		
53	35		LSB	117	75		
54	36		LSB	118	76		
55	37		LSB	119	77		
56	38		LSB	120	78	ALL SOUND OFF	
57	39		LSB	121	79	ALL CONTOLLERS OFF	
58	3A		LSB	122	7A	LOCAL ON/OFF	
59	3B		LSB	123	7B	ALL NOTES OFF	
60	3C		LSB	124	7C	MODE OMNI OFF	
61	3D		LSB	125	7D	MODE OMNI ON	
62	3E		LSB	126	7E	MODE MONO	
63	3F		LSB	127	7F	MODE POLY	